


NEXT DOCK – FIRMWARE UPDATE INSTRUCTIONS (FOR MAC)


Please visit link below to get the MAC software:

<https://next-accessories.com/NXNS2DK> OR <https://next-accessories.com/download>



1. Connect your NEXT Dock to your MAC using a USB cable


- Use a direct USB port on your computer (avoid USB hubs if possible).
- Do not disconnect your Nintendo Switch console during this process.



2. After extracting the firmware file, Navigate the folder and double-click the installer. Click the 'Continue' button at the bottom right corner of the interface to proceed with the installation.

- The update process will take less than one minute.

3. Once you're in the application, Locate the update firmware file and double-click to run it.



4. Wait until the update is complete.

- Do not disconnect the dock or turn off your computer during the update.

5. When finished, disconnect the dock and reconnect it to your Nintendo Switch 2.



-----Troubleshooting-----

- If your computer doesn't recognize the dock, try a different USB port or cable.